

Key Features

- High speed: 70 kHz
- 100 % fill factor
- Low noise
- · Ease of integration
- Common electrical and mechanical interface

Typical Applications

- Web inspection
- Recycling
- · Document scanning

A Fast and Responsive 4K Single Line Monochrome CMOS Imaging Sensor

The IT-K3-04120 sensor is a high performance, digital, single line scan monochrome CMOS image sensor. The sensor is optimized for a high line rate and low noise, while providing high responsivity and high quantum efficiency (QE). The sensor is designed for ease-of-integration and uses FR4 packaging.

The pixel features global shutter capability, 100% fill factor, and true correlated double sampling (CDS) for low noise.

FR4 packaging offers high signal integrity and simple interfacing for quick system integration. The interface consists of two 60-pin connectors, which contain input signals, such as EXSYNC (trigger), clocks and voltages, and output signals, such as data and strobe (s-LVDS). Access to the registers of the sensor is handled through a serial-peripheral interface (SPI), plus the temperature of the sensor can be monitored.

The two 60-pin connectors on the IT-K3 share the same electrical and mechanical interface with the entire IT-K and IT-L sensor series, whereby the two 60-pin connectors and four mounting holes are positioned identically relative to one another as well as pin compatibility.

Specifications

Random Noise 1.9 DN

Dynamic Range 66 dB

Conversion Gain 0.20 DN/e

Full Well 19 ke

Shutter Type Global shutter

Responsivity 210 DN / nJ / cm² @ 12-bit, peak

Power Consumption 2 V

Operating Temperature 0° to +60°C Package FR4 Regulatory Compliance RoHS

Models			
Part Number	Resolution	Maximum Line Rates	Pixel Size
IT-K3-04120-00-R	4120 x 1	70 kHz	7.04 μm x 7.04 μm


Camera part number for sensor evaluation: LA-CM-04K08




IT-K3-04120

4K Single Line Monochrome CMOS Imaging Sensor





Note: Savitsky-Golay filtering applied, with 40 nm window and 1st order polynomial.



© 2016 Teledyne DALSA

All information provided in this document is believed to be accurate and reliable. No responsibility is assumed by Teledyne DALSA for its use. Teledyne DALSA reserves the right to make-changes to this information without notice. Reproduction of this document in whole or in part, by any means, is prohibited without prior permission having been obtained from Teledyne DALSA. All trademarks or intellectual property mentioned herein belong to their respective owners.

About Teledyne DALSA

Teledyne DALSA is an international high performance semiconductor and electronics company that designs, develops, manufactures, and markets digital imaging products and solutions, in addition to providing wafer foundry services.

Teledyne DALSA Digital Imaging offers the widest range of machine vision components in the world. From industry-leading image sensors through powerful and sophisticated cameras, frame grabbers, vision processors and software to easy-to-use vision appliances and custom vision modules.

Teledyne DALSA is headquartered in Waterloo, Ontario, Canada. We have sales offices in the USA, Europe and Asia, plus a worldwide network of representatives and agents to serve you efficiently.

www.teledynedalsa.com

Americas

Boston, USA +1 978-670-2000

sales.americas@teledynedalsa.com

Europe

Krailling, Germany +49 89-89-54-57-3-80

sales.europe@teledynedalsa.com

Asia Pacific

Tokyo, Japan +81 3-5960-6353

+81 3-5960-6353 sales.asia@teledynedalsa.com Shanghai, China +86 21-6427-9081 sales.asia@teledynedalsa.com

