VTC FALL 2011

Exploring the Use of Two Antennas for Crosscorrelation Spectrum Sensing

M.S. Oude Alink, A.R. Smeenge, A.B.J. Kokkeler, E.A.M. Klumperink, G.J.M. Smit and B. Nauta Integrated Circuit Design / Computer Architecture for Embedded Systems CTIT Research Institute, University of Twente, Enschede, The Netherlands Email: m.s.oudealink@utwente.nl

Abstract—Spectrum sensing is one of the key characteristics of a cognitive radio. Energy detection provides maximum flexibility by not relying on any prior knowledge, but suffers from an SNRwall due to noise uncertainty. Crosscorrelation of the outputs of two receiver paths is a technique to reduce the noise level of the total receiver, and hence improves the SNR. In this paper we explore the use of two antennas for crosscorrelation spectrum sensing, as the ultimate noise floor in a previously published prototype was mainly limited by correlated noise originating from shared components near the (single) antenna. Our results indicate that a lot of the correlated noise in the prototype can be removed, but that care should be taken in the antenna placement to not lose too much of the signal to be detected due to time delay, Doppler effect and fading. Although more research is required, the preliminary conclusion is that the use of two antennas in a compact mobile device provides more advantages than disadvantages for croscorrelation spectrum sensing, which makes it an interesting solution to more reliable energy detection.

Index Terms—antennas, cognitive radio, crosscorrelation, energy detection, noise correlation, noise uncertainty, radiometer, SNR-wall, spectrum sensing

I. INTRODUCTION

OGNITIVE RADIO (CR) is a paradigm to a more efficient usage of spectrum. Instead of being assigned to fixed frequency bands, a CR scans the spectrum and opportunistically uses available frequencies. Energy detection would be preferable, because it allows a CR to operate in any possible frequency band, without the requirement to know anything about the type of signals present in such a band. It has the disadvantage that due to uncertainty in the noise level, a minimum signal-to-noise ratio (SNR) exists below which a signal cannot be reliably detected [1]. This minimum SNR is called the SNR-wall.

Crosscorrelation is proposed to reduce this SNR-wall for energy detection [2]. The idea is to have two receiver paths, such that the noise added by each path is uncorrelated with the noise in the other path. A spectrum analyzer (SA) that uses crosscorrelation to lower the noise level is described in [3], which we will refer to as the crosscorrelation spectrum analyzer (XCSA). By crosscorrelating the output of two receiver paths, the uncorrelated noise is removed, reducing the noise floor from -150 dBm/Hz to -170 dBm/Hz. Intuitively, when the noise is eventually removed, any uncertainty of its power does not matter. This is mathematically quantified in [2], showing that the minimum signal power that can be




Fig. 1. Energy detection using crosscorrelation.

detected depends on the noise figure (NF) of the system, the noise uncertainty and the noise correlation factor between the two receiver paths. Noise uncertainty can be minimized by on-line calibration, but there will always be some remaining uncertainty [4]. Therefore, it is desirable to minimize the NF and the noise correlation.

The XCSA uses a single antenna followed by a passive splitter, and most of the noise correlation originates from components that are shared by the two receivers. In this paper, we investigate the use of a separate antenna for each receiver, such that no components are shared, improving the NF and reducing the noise correlation. The use of multiple antennas is getting more and more accepted, as it is used in diversity receivers, for beamforming and MIMO-systems, and has been proposed in many other works on spectrum sensing. To the best of our knowledge, we are the first to discuss the signal and noise correlation between multiple antennas in the context of crosscorrelation spectrum sensing.

This paper is organized as follows. In section II we will briefly summarize the key aspects of crosscorrelation spectrum sensing and the prototype of [3]. We will then start to investigate the impact of using two antennas on the noise level in section III, which includes some measurements. A discussion on the impact on signal detection is given in section IV, while we end with conclusions in section V.

II. CROSSCORRELATION SPECTRUM SENSING

For the purpose of noise analysis, the receiver chain, which typically includes an LNA, mixer, amplifiers, prefilters and an analog-to-digital converter (ADC), is modeled as a device that only adds some noise. For a crosscorrelation system

2 VTC FALL 2011




Fig. 2. Prototype (one antennas) and proposed system (two antennas).

(part of) the receiver chain is duplicated, where uncorrelated noise is added in each of the two paths, see fig. 1. When these separate paths generate correlated noise, e.g. through shared components, such as the splitter resistors, or (parasitic) coupling, such as the antenna(s) or the power supply, the correlated noise part can be moved to $n_{\rm corr}$ without loss of generality. The signal plus correlated noise x is filtered in each path by a filter with bandwidth W and then sampled at the Nyquist rate, resulting in the complex receiver outputs r_1 and r_2 . The energy detection is performed by multiplying r_1 and r_2 (r_2 denotes the complex conjugate of r_2), and averaging the result. This final output y is used to decide whether a signal is present or not.

Assuming the signal and all noise sources are uncorrelated, we find

$$\mathbb{E}\left[y\right] = \mathbb{E}\left[r_{1}\overline{r_{2}}\right] = \mathbb{E}\left[\left(x+n_{1}\right)\overline{\left(x+n_{2}\right)}\right]$$

$$= \mathbb{E}\left[\left|x\right|^{2}\right] + \mathbb{E}\left[x\overline{n_{2}}\right] + \mathbb{E}\left[n_{1}\overline{x}\right] + \mathbb{E}\left[n_{1}\overline{n_{2}}\right]$$

$$= \mathbb{E}\left[\left|x\right|^{2}\right] = \mathbb{E}\left[\left|s\right|^{2}\right] + \mathbb{E}\left[\left|n_{\text{corr}}\right|^{2}\right] = P_{s} + P_{n_{\text{corr}}}$$
(1)

where $\mathbb{E}\left[\cdot\right]$ denotes the expectation operator. In other words, the uncorrelated noise power is removed using the crosscorrelation process, while the signal power and the correlated noise power remain. Note that for autocorrelation, $r_1=r_2$ and $n_1=n_2=0$, with n_{corr} containing *all* of the noise of the receiver, which is *not* removed. The removal of the uncorrelated noise power increases the SNR, and therefore allows smaller signals to be detected [2].

The prototype presented in [3] uses one antenna, and then splits the signal into two paths using resistors. Each path is then attached to its own receiver, which consists of a resistive attenuator, a mixer, amplifiers and an ADC. This is schematically depicted in fig. 2a. The noise voltage generated by each resistor in the splitter and the attenuators will be present at the input of both receivers (although possibly with different amplitudes due to the network transfer) because there is no isolation between them. From measurements in [3], $P_{n_{\rm corr}}\approx -170~{\rm dBm/Hz},$ which leaves room for improvement.

Therefore, we propose the use of a separate antenna for each receiver, such as depicted in fig. 2b. This scheme has the direct advantage of reducing the NF of the system (before crosscorrelation) by 6 dB due to the removal of the resistive splitter, reducing measurement time significantly. It is, however, not directly clear what the noise correlation and the signal correlation on the two antennas will be. This is the topic of the next sections.

III. NOISE CORRELATION IN TWO ANTENNAS

We will first briefly explain the origin of noise in a single antenna, and then proceed to describe factors introducing noise correlation in two antennas. We end this section with some measurements on noise correlation.

A. Noise in an Antenna

Black-body radiation is the electro-magnetic (EM)-radiation emitted by a black body at a given temperature. Real-life objects are not perfect black bodies (as can be observed in the visible range of the spectrum), but the approximation is very good in the radio frequency range [5]. From the Rayleigh-Jeans approximation (accurate for frequencies up to tens of GHz), the radiation of a black body (also referred to as brightness) is

$$B_{\text{black-body}} \approx \frac{2kT}{\lambda^2} \left[\mathbf{W} \cdot \mathbf{Hz}^{-1} \cdot \mathbf{m}^{-2} \cdot \mathbf{sr}^{-1} \right]$$
 (2)

where k is Boltzmann's constant $(1.38 \cdot 10^{-23} \text{ J/K})$, T is the absolute temperature in Kelvin, and $\lambda = c/f$ is the wavelength, with c the speed of light $(3.00 \cdot 10^8 \text{ m/s})$ and f the frequency in Hz.

The purpose of an antenna is to transport the energy of the incident EM field to the load. The maximum power that can be delivered by the antenna to the load is called the available power $P_{\rm av}$ (we denote the available power per Hertz, or the available power spectral density (PSD), as $S_{\rm av}$). This maximum power transfer is obtained under conjugate matching, which is assumed from here on. The received EM field is the summation of the emitted EM fields by all surrounding objects. When the antenna is completely surrounded by black bodies in thermal equilibrium, $S_{\rm av} = kT$ [W/Hz]. The noise floor, taken as kT, with T=290 K, is then -174 dBm/Hz. So, even when the antenna itself is noiseless, which we assume from here on, it will deliver noise power to the attached receiver.

B. Factors Introducing Noise Correlation in Two Antennas

Many papers on spectrum sensing with multiple antennas assume independent noise samples at each antenna. There are, however, several factors that introduce correlated noise between two antennas.

- 1) Mutual Coupling: The EM-field impinging on one antenna induces a time-varying current in the antenna, which by itself generates an EM-field. This EM-field may be received by another antenna, which is the reason for mutual coupling. Mutual coupling will also introduce correlation of the noise generated by the receiver, as some noise generated in one receiver will be transmitted by its antenna, and then received by the other [6]. Hence, mutual coupling introduces correlated noise.
- 2) Spatial Correlation: In [7], it is shown that, even when there is no antenna coupling, the thermal noise of two closely spaced antennas can be correlated due to spatial correlation. The crosscorrelation function (ccf) $\gamma_{x,y}(\tau) = \mathbb{E}\left[V_x(t)V_y(t+\tau)\right]$ between the voltages induced on the antenna terminals by these noise sources depends on the distance d between the antennas, the antenna patterns, and the polarization the antennas are sensitive to [7].

3) Man-made Noise: A receiver tries to receive information from one 'wanted' radiator, but there are many other radiators in that band, such as other transmitters, lossy cables, but also stellar objects and lightning. Other than the natural sources, these are often collectively combined into 'man-made noise'. Man-made noise, just like the black-body radiation, originates from many sources and arrives from many directions, so it will also have spatial correlation.

C. Measurements

To verify noise decorrelation in practice, we have performed measurements. Two signal generators are used to represent two independent bandlimited white real noise sources, with a bandwidth of roughly 1 MHz. We can obtain the estimated PSD $\mathcal{S}_n(f)$ for two noise sources n_{src1} and n_{src2} as:

$$S_n(f) = S_{n_{\text{src}1}}(f)e^{-j2\pi f \tau_1} + S_{n_{\text{src}2}}(f)e^{-j2\pi f \tau_2}$$
 (3)

where τ_i denotes the delay between the two antennas as seen from source i. By integrating over the bandwidth of interest f_b , we then obtain the estimated power \mathcal{P}_n . By dividing \mathcal{P}_n by the total power P_n , we obtain the noise correlation factor ρ :

$$\rho \triangleq \frac{\mathcal{P}_n}{P_n} = \frac{1}{f_b \left(P_{n_{\text{src1}}} + P_{n_{\text{src2}}} \right)} \int_{f_0 - f_b/2}^{f_0 + f_b/2} \mathcal{S}_n(f) \, \mathrm{d}f$$

$$\approx \frac{1}{2} \int_{f_0 - f_b/2}^{f_0 + f_b/2} e^{-j2\pi f \tau_1} + e^{-j2\pi f \tau_2} \, \mathrm{d}f$$
(4)

In the second step it is assumed that $P_{n_{\rm src1}} \approx P_{n_{\rm src2}}$, as is the case for the measurements.

The setup resembles an XCSA as it would be used in practice, as shown in fig. 3a, and uses two transmit and two receive antennas, positioned as shown in fig. 3b. The receiver downconverts, amplifies and filters the signal before it is digitized. The crosscorrelation is then performed as described in [3]. By transmitting enough power, we made sure that the two noise sources dominate all man-made noise and interference.

Figure 3c shows the theoretical correlation factor (eq. (4)) and the measured correlation factor for an antenna separation of 50 cm: $\tau_1 = -\tau_2 = \frac{d}{c} \approx 1.67$ ns. Clearly, the measurements do not follow the simple theory. The measurements were repeated for other antenna separations, again showing similar chaotic results. We believe that the difference between theory and measurements is caused by multi-path effects, which can be completely different for different frequencies. This would explain the erratic behavior of the correlation factor over frequency, and suggests that in a realistic (indoor) environment, such as the lab in which the experiments were conducted, the noise correlation can deviate a lot from a simple first-order model. Since we do not have access to an anechoic chamber to verify this, we repeated the experiments with cables of different lengths to replace the antennas and avoid multipath propagation, but still mimic the time delay. The results are shown in fig. 3d, which clearly gives a much better match.




Fig. 3. Measurement of the correlation factor for two noise sources.

By looking at fig. 3c and averaging $|\rho|$, $|\rho| \approx 0.7$. This means that with two antennas, the noise between the antennas is partially decorrelated.

(d) Measurement results when using cables

IV. SIGNAL DETECTION WITH TWO ANTENNAS

When both the noise and the signal correlation are reduced by the same factor, the SNR is not changed, and neither will the ultimate sensitivity of a XCSA. Therefore, it is equally important to consider the signal correlation in the two-antenna XCSA. To achieve insight into this effect, we will explore the signal correlation for a few different scenarios assuming identically polarized antennas without mutual coupling.

A. Time-delay in line-of-sight (LOS)-connections

In LOS-connections, there will be a time delay between the signal arriving on the first and the second antenna, depending on the orientation of the antennas with respect to the signal source. This time delay is unknown, because the angle of arrival of the signal is unknown. Mathematically, we find at the

4 VTC FALL 2011

output of the crosscorrelator $S_s(f) = S_s(f)e^{-j2\pi f \tau_0}$, where τ_0 is the time delay. Hence, if we use the absolute value of $S_s(f)$, we find $|S_s(f)| = S_s(f)$ (note that the PSD of a signal is always real and nonnegative). The total power \mathcal{P}_s in a band ranging from $f_0 - \frac{f_b}{2}$ to $f_0 + \frac{f_b}{2}$ is then simply found by integrating $|S_s(f)|$ over this frequency range.

The minimum bandwidth that can be estimated is inversely proportional to the measurement time, so we have to consider detection in a finite bandwidth f_b . Each frequency within f_b will experience a different phase shift between the two antennas. As, due to the time delay, the estimated spectrum can be complex, we again take the absolute value. For simplicity, we assume the signal is a white noise source in the band of interest, which is a good approximation of for example OFDM-signals. The estimated power then becomes

$$\mathcal{P}_s = \left| \int_{f_0 - \frac{f_b}{2}}^{f_0 + \frac{f_b}{2}} \mathcal{S}_s(f) \, \mathrm{d}f \right| = P_s \left| \left(\frac{\sin \pi f_b \tau_0}{\pi f_b \tau_0} \right) \right| \tag{5}$$

Clearly, for $f_b = 0$ and/or $\tau_0 = 0$, $\mathcal{P}_s = P_s$. For larger τ_0 and/or larger f_b , the measured power \mathcal{P}_s becomes lower. If we maximally want to lose 1 dB of signal power, we find

$$f_b \cdot \tau_0 \lesssim 0.36. \tag{6}$$

Consider the use of the TV white space, with channels of 6 MHz. From eq. (6) we find $\tau_0 \leq 60$ ns. In a handheld device, the maximum distance $d_{\rm max}$ between the two antennas will be about 15 cm, so the maximum time delay is $\tau_{\rm max} = \frac{d}{c} \approx 0.5$ ns, which gives negligible loss in signal power. Even when the antennas would be 10 m apart, the detected signal power will only be lowered by 0.3 dB.

B. Movement in LOS-connections

In the previous section, it was assumed that everything was static. Especially in a mobile context, the transmitter and/or the spectrum sensing device can move during the sensing process, which makes some parameters dynamic.

Consider the situation depicted in fig. 4, where the transmitter moves during the sensing process, such that at time instant t, it is located at p_t , while the two receive antennas, located at p_x and p_y , are stationary. The two receive antennas are separated by a distance d_a , and the transmitter moves at a uniform velocity v. We assume the signal power received by each antenna does not change, but the relative phase between the two antennas does, which is just the Doppler-effect. The largest change in phase is obtained if the transmitter moves as indicated: parallel to the baseline of the antennas, passing point p_0 (at distance $d_{tx,rx}$ from the baseline) halfway during the sensing process, which takes T seconds. The distance d_{p_1,p_2} between p_1 and p_2 covered by the transmitter during the sensing process is thus $d_{p_1,p_2} = vT$.

the sensing process is thus $d_{p_1,p_2}=vT$. We define $d_{p_t,p_0}(t)=v\left(\frac{T}{2}-t\right)$ and $\Delta d(t)=d_{p_t,p_x}(t)-d_{p_t,p_y}(t)$, where $d_{p_t,p_x}(t)\geq 0$ and $d_{p_t,p_y}(t)\geq 0$. Then we find for the phase difference between the two receivers $\Delta\phi(t)=2\pi f\frac{\Delta d(t)}{c}$ (note that $\Delta d(t)$ can become negative). Considering




Fig. 4. Simple model of a moving transmitter and stationary two-antenna XCSA.

a single frequency, the estimated PSD $S_s(f)$ of the true PSD $S_s(f)$, after measuring for T seconds, is then

$$S_s(f,T) = \frac{1}{T} \int_0^T S_s(f) e^{j\Delta\phi(t)} dt = S_s(f) \cdot \frac{1}{T} \int_0^T e^{j\Delta\phi(t)} dt$$
(7

This integral is difficult to evaluate analytically for given $\Delta\phi(t)$, but we can simplify the result for certain situations.

For small vT we can use a Taylor-series approximation for d_{p_t,p_x} and d_{p_t,p_y} , resulting in $\Delta d(t) \approx d_a d_{p_t,p_0}(t)/r$, where $r = \sqrt{(d_a/2)^2 + d_{tx,rx}^2}$. The signal power estimate then becomes

$$S_s(f) \approx \frac{1}{T} S_s(f) \int_{-T/2}^{T/2} e^{-j2\pi f \frac{d_a vt}{cr}} dt = S_s(f) \frac{\sin\left(\frac{\pi v T f d_a}{rc}\right)}{\left(\frac{\pi v T f d_a}{rc}\right)}$$
(8)

To maximally lose 1 dB of estimated signal power, $vTfd_a \lesssim 0.36rc$.

For very large vT, the integral is mainly determined by the transmitter being at the far left or the far right of the receiver, so we find $\Delta d(t) \approx \pm d_a$, resulting in

$$S_s(f) \approx S_s(f) \cos\left(2\pi f \frac{d_a}{c}\right)$$
 (9)

In order to guarantee a maximum loss of 1 dB of estimated signal power for arbitrary measurement time, $d_a \lesssim 0.1 \frac{c}{f} = 0.1 \lambda$.

We can numerically evaluate the integral of eq. (7) for some practical cases. Consider the detection of a wireless microphone, operating at a center frequency of 500 MHz, at a distance $d_{tx,rx}=20$ m. The two antennas of the XCSA are 10 cm apart ($d_a\approx 0.17\lambda$). With a velocity of 1.6 m/s (a person carrying the microphone), the maximum measurement time $T_{\rm max}$ to lose not more than 1 dB of signal power is $T_{\rm max}\approx 43$ s, which is much longer than required by IEEE 802.22. Next, consider the detection of a signal in the ISM-band at 2.4 GHz with a laptop that has two antennas at a distance of 30 cm ($d_a=2.4\lambda$). The signal is transmitted from a car moving at 30 m/s with $d_{tx,rx}=50$ m. Now we find $T_{\rm max}\approx 190$ ms. Note that using the approximate eq. (8), we find $T_{\rm max}\approx 250$ ms.

These practical cases show that only for large antenna distances and fast-moving transmitters and/or excessive measurement time, the signal can be decorrelated significantly. Under these LOS-assumptions, it is clear that a two-antenna XCSA is applicable in many situations.

C. Fading

Many connections are not LOS, but rely on multi-path reflections. Diversity is often used to improve the performance of a communications system in these fading channels, and is based on the idea that with multiple antennas, the probability that at least one of them is not in a deep fade is increased. The simplest fading channel is a Rayleigh fading channel, where the instantaneous amplitude $A = \sqrt{X^2 + Y^2}$ is Rayleigh distributed, and the phase is uniformly distributed. Here, X and Y are the real and imaginary parts of the received signal, both normally distributed with zero mean and var[X] = $var[Y] = \sigma^2/2$. The output power of an energy detector with one antenna will then be $\mathcal{P}_s = \mathbb{E}[A^2] = \sigma^2 = P_s$. We wish to compare the signal power at the output of the two-antenna XCSA with the signal power at the output of the one-antenna XCSA. Here we do not consider noise, so a oneantenna XCSA will give the same result as any energy detector using one antenna.

The crosscorrelation system is sensitive to phase variations during the measurement, as was established in section IV-B. Therefore, a good channel model is required that describes the phase-correlation over time and location. Because we do not have that at our disposal yet, here we present a simplified model to serve as a first starting point, where we assume a channel in which the amplitudes of the signal undergo (correlated) fading, but the phase difference of the signal between the two antennas remains constant during the measurement. Note that a constant phase difference over frequency between the two antennas of the receiver can be handled by taking the absolute value as in the LOS-connection, so here we assume a phase difference of 0.

With received signal amplitudes A_1 and A_2 at antenna 1 and 2, respectively, the crosscorrelator will output $\mathcal{P}_s = A_1 A_2$ as power. In the case of fading, A_1 and A_2 are random variables, with $A_i \geq 0$, and so is \mathcal{P}_s . We assume that the average signal power received by both antennas is equal $(\mathbb{E}\left[A_1^2\right] = \mathbb{E}\left[A_2^2\right])$, which is a well-accepted model [8]. When the fading is fully correlated, i.e., $A_1 = A_2$, we get $\mathcal{P}_s = \sigma^2 = P_s$ as for the single-antenna case. For independent fading, we get $\mathcal{P}_s = \mathbb{E}\left[A_1A_2\right] = \mathbb{E}\left[A_1\right]\mathbb{E}\left[A_2\right] = \sqrt{\frac{\pi}{4}}\sigma\sqrt{\frac{\pi}{4}}\sigma = \frac{\pi}{4}\sigma^2$. These are the two extreme cases, so for correlated fading the result will be somewhere in between: $\frac{\pi}{4}P_s \leq \mathcal{P}_s \leq P_s$. Maximally $10\log_{10}\frac{4}{\pi}\approx 1$ dB of signal power is lost, provided the relative phase does not change during the measurements.

V. CONCLUSIONS

In previous work, it has been shown that crosscorrelation of the outputs of two receivers attached to a single antenna can significantly lower the noise level of an energy detector for spectrum sensing. In this work, in an effort to improve the noise performance even further, we explored the use of two receivers with each receiver attached to its own antenna (often already available as beamforming, diversity reception and

MIMO systems become more popular). The use of two antennas turns out to have both positive effects (noise decorrelation and lower NF) and negative effects (signal decorrelation).

By using two antennas, shared components between the receivers can be removed, which reduces the noise correlation, but also improves the NF of the receiver by 6 dB, reducing measurement time significantly. We identified the different mechanisms that still cause residual noise correlation as mutual coupling, spatial correlation, and man-made noise. The spatial correlation of noise received by the antennas will ultimately limit the reduction of the noise level, even in the absence of mutual coupling. Presented measurements verify the decorrelation of noise using two antennas, but indicates that multipath effects can play a significant role.

Although the use of two antennas improves the noise performance, we also showed that it can degrade the signal power detected. This is caused by decorrelation of the signal, due to 1) the physical distance between the antennas, 2) the presence of relative signal phase shift between the antennas due to Doppler shift, and 3) the presence of fading.

Only modest noise decorrelation was experimentally observed in a lab-environment (-1.5 dB), but this reduction, in combination with 6 dB improvement in NF and a relatively low loss of detected signal power in several scenarios, allows us to conclude that the use of two antennas instead of one provides performance benefits for an XCSA, making it a promising option that deserves further exploration.

ACKNOWLEDGMENT

We would like to thank F. van Vliet and M. Bentum for fruitful discussions, ASTRON for providing the dipole antennas used in the measurements, and H. de Vries and G. Wienk for practical assistance. This research is supported by the Dutch Technology Foundation STW, applied science division of NWO and the Technology Program of the Ministry of Economic Affairs (project 08081).

REFERENCES

- [1] R. Tandra and A. Sahai, "SNR walls for signal detection," *IEEE J. Sel. Topics Signal Process.*, vol. 2, no. 1, pp. 4–17, 2008.
- [2] M. S. Oude Alink, A. B. J. Kokkeler, E. A. M. Klumperink, G. J. M. Smit, and B. Nauta, "Lowering the SNR-wall for energy detection using crosscorrelation," *submitted to IEEE Trans. Veh. Technol.*
- [3] M. S. Oude Alink, E. A. M. Klumperink, M. C. M. Soer, A. B. J. Kokkeler, and B. Nauta, "A 50MHz-to-1.5GHz cross-correlation CMOS spectrum analyzer for cognitive radio with 89dB SFDR in 1MHz RBW," in Proc. 4th IEEE Symp. on New Frontiers in Dynamic Spectrum Access Networks (DySPAN), 6-9 Apr. 2010, pp. 1–6.
- [4] R. Tandra and A. Sahai, "Noise calibration, delay coherence and SNR walls for signal detection," in *Proc. 3rd IEEE Symp. on New Frontiers in Dynamic Spectrum Access Networks (DySPAN)*, 2008, pp. 1–11.
- [5] J. H. Shirley and R. W. Fairbridge, Eds., Encyclopedia of Planetary Sciences. Springer, 1997.
- [6] C. P. Domizioli, B. L. Hughes, K. G. Gard, and G. Lazzi, "Noise correlation in compact diversity receivers," *IEEE Trans. Commun.*, vol. 58, no. 5, pp. 1426–1436, 2010.
- [7] D. Childers and I. Reed, "Space-time cross-correlation functions for antenna array elements in a noise field," *IEEE Trans. Inf. Theory*, vol. 11, no. 2, pp. 182 – 190, apr 1965.
- [8] L. Fang, G. Bi, and A. C. Kot, "New method of performance analysis for diversity reception with correlated rayleigh-fading signals," *IEEE Trans.* Veh. Technol., vol. 49, no. 5, pp. 1807–1812, 2000.